

KleenLine™ Pro Foaming Oven Cleaner



CATEGORY & ICON
Kitchen

ITEM #KL-AEROVENCLNR (20 OZ - TWELVE PER CASE)

Formulated for hard-to-clean ovens and grills in high-traffic kitchens, this product cleans with less effort than conventional cleaners. It is excellent for cleaning ovens, grills, pots, and pans by removing baked-on deposits with reduced scraping and scouring. This effective cleaner is safe to use on porcelain, glass, ceramics, stainless steel, and cast-iron surfaces. However, do not use this product on aluminum.

PRODUCT FEATURES

- » Effective - Cleans and removes baked-on deposits
- » Versatile - Use on a variety of surfaces
- » Saves Time - Reduces scraping and scouring

PRODUCT SPECIFICATIONS

Brand	KleenLine™ Pro
Product Category	Kitchen Cleaner
Color	Colorless
Fragrance	Solvent
pH	13.5
Unit of Measurement / Amount per case	20 oz / 12/cs
UPC Barcode	810037737141

INGREDIENTS

Aqua, Sodium Hydroxide , Butane, Butoxydiglycol, Propane and Surfactants. Before using, consult supplier for further information and precautions, including Safety Data Sheet.

DIRECTIONS FOR USE

This effective cleaner is safe to use on porcelain, glass, ceramics, stainless steel, and cast-iron surfaces. Keep spray or drippings away from the pilot lights, electrical connections, switches, receptacles, thermostats, heating elements, light bulbs, and other surfaces which might be affected by caustics. Avoid contact with painted or varnished surfaces, clothing, floor tile, linoleum, plastics, chrome, copper, aluminum, and copper tone surfaces. Not for use on self-cleaning or continuous cleaning ovens. Place newspaper under oven door to protect floor. Wear rubber gloves to avoid skin contact.

1. Use on empty oven, either cold or pre-heated to 200°F and turned off. TURN OFF PILOT LIGHT and/or ELECTRIC SWITCH.
2. Hold can upright and point spray button away from face. SHAKE WELL, then spray inside of oven from a distance of 8 to 12 inches, giving it an even coating.
3. Spray top and bottom of oven first; then spray remaining oven surfaces and allow to stand about 30 minutes. (May be left on overnight with oven door closed.)
4. Wipe oven clean with damp cloth, sponge, or paper towel. Spots that are difficult to remove should be retreated and cleaned with a scouring pad. Rinse with potable water.
5. When clean, re-ignite pilot light, or turn on electric switch, and heat oven to 400°F for 10 minutes before using with food again.

EXPERTLY DESIGNED FOR PROFESSIONALS!

KleenLine™ Pro is an exclusive BradyPLUS product line for the Facility Care market. The wide range of products enables customers to meet budget and cleaning objectives and solve all cleaning challenges from the simplest to the most complex. KleenLine™ Pro provides quality tools and solutions that are built to withstand the demands of the professional and assist with doing the job more effectively and efficiently.



Exclusively available through BradyPLUS and our Regional Distribution Brands
BradyPLUS.com + (877) 788-PLUS