



Time in Service™ Monitor Instructions



Hygomat's exclusive 1 Month Time in Service Monitor (TSM) indicates how long the mat has been in service. This allows you to determine when it is time to replace the Hygomat.

1. **TO ACTIVATE** Press the raised circle bubble firmly with the thumb and fingers before placing the Hygomat on the floor.



2. The applied pressure will force the blister beneath the circle to break and a pop like sound may be heard.
3. The TSM will confirm that it has been properly activated when the appearance of a faint black line on the right side of the TSM indicator is visible.
4. Position the Hygomat on the floor as usual in front of the urinal or commode. Within an hour of activation, the faint black line will become red.
5. The red line will continue to move slowly through the white colored timestrip bar.
6. Based on the restroom traffic, replace the Hygomat when the red line reaches the designated week (the specific 4 weeks per month are designated by the notches in the timestrip).

Heavy traffic 400+ users per day – Replace 5 to 7 days
Medium traffic 200+ users per day – Replace every 2 – 4 weeks
Light traffic 50+ users per day – Replace every 4 weeks



* Red line will advance quickly in the beginning but will slow down and read accurately after one day.



Q. WHAT IS HYGOMAT?

A. Hygomat is a disposable, cost effective, and attractive restroom floor mat used to absorb and eliminate odors associated with urine drips.

Q. HOW DOES IT WORK?

A. The ADA compliant slip resistant Hygomat is placed under urinals or commodes with a double sided tape that keeps the mat securely in place.

Q. WHAT ARE THE BENEFITS OF USING HYGOMAT?

A. Hygomat kills the offensive odors caused by bacteria in urine and keeps restroom floors cleaner and drier while reducing restroom maintenance, labor costs, and slip and fall liability. It also protects grout and tile and prolongs life of floor by preventing the unsightly spread of urine throughout the restroom by the feet of bathroom users.

Q. WHAT MAKES HYGOMAT BETTER THAN OTHER URINAL MATS?

A. Unlike other mats on the market today, Hygomat stays in place, will not discolor or show urine drips, permanently kills odor causing bacteria rather than masking it with a fragrance, and is easy to dispose of using standard waste management procedures.

Q. WHAT IS THE ANTIMICROBIAL AGENT USED ON HYGOMAT?

A. Each Hygomat is treated with Ultra-Fresh, an environmentally safe and non-toxic antimicrobial agent that is found in many common household items such as pantyhose, sheets, socks, and towels.

Q. HOW LONG WILL MY HYGOMAT WORK?

A. Each mat is sprayed with the antimicrobial agent before it is shipped out and will last for at least a year. All mats are embedded with our exclusive "Time in Service" monitor strip that indicates how long the mat has been in service and when it is time to change the mat.

Q. WILL HYGOMATS BECOME SATURATED AND LEAK THROUGH TO THE RESTROOM FLOOR?

A. The bottom layer of the Hygomat has a reinforced backing that stops urine from reaching the floor. The top layer of the mat is designed to instantly pull the moisture away from the surface, so that even if you step on the mat, you will not get urine on your shoes. Under normal conditions, a Hygomat can handle a sustained rate of 30 drips per hour without becoming saturated.

Q. WHERE ELSE CAN I USE THE HYGOMAT?

A. It can be placed on the floor under water coolers and beverage machines, or under coffee pots, pet dishes, or any where else that excess moisture is a problem.

Q. HOW DO I INSTALL THE HYGOMAT?

A. Thoroughly clean floor and grout with an enzyme-based floor cleaner and allow to completely dry. Peel off protective strip from adhesive tape. Place mat with adhesive tape edge furthest away from urinal or commode. Secure to floor. There is no need to remove Hygomat during mopping. MOP AROUND, NOT OVER Hygomat.

Set up and adhere to a consistent replacement schedule:

HEAVY TRAFFIC 400 +/- Users Per Day	MEDIUM TRAFFIC 200 +/- Users Per Day	LIGHT TRAFFIC 50 +/- Users Per Day
Casinos, bars, theaters, fast food outlets.	Restaurants, hotels, clinics, hospitals, schools.	Offices, retail stores, medical offices.
Replace every 5-7 days	Replace every 2-4 weeks	Replace every 4 weeks



Hygomat is a registered trademark.
2004 copyrighted material.
Revision 3/15/2012